





ITMH01 外形及安装尺寸/ ITMH01 Installation Dimensions




标准外花键 : ITMH01---
Standard Involute Spline : ITMH01---




标准平键 : ITMH01---B
Standard Parallel Key : ITMH01---B




ITMH01---B₂₈



ITMH01---B₃





ITMH01---B₁₁、B₁₁-1



型号	d
B ₁₁	25
B ₁₁ -1	25.4


ITMH02 外形及安装尺寸/ ITMH02 Installation Dimensions




标准外花键 : ITMH02-***
Standard Involute Spline :

标准平键 : ITMH02-***B
Standard Parallel Key :


标准内花键 : ITMH02-***I
Standard Female Spline :





ITMH02-***SL₁




ITMH02-***B₁、B₂




ITMH02-***B₂₄




型号	D	D ₁
B ₃	160	125
B ₃	127	100




ITMH02--**B₃




ITMH02--**B₁₄




ITMH02--**I₀₁、I₀₂



ITMH02--**I₀₃




ITMH03 外形及安装尺寸/ ITMH03 Installation Dimensions




标准外花键 : ITMH03---
Standard Involute Spline : ITMH03---

标准平键 : ITMH03---B
Standard Parallel Key : ITMH03---B


标准内花键 : ITMH03---I
Standard Female Spline : ITMH03---I




ITMH03---B₁




ITMH03---SL₁




ITMH03---SL₂, SL₃




ITMH03--**B₂



ITMH03--**B₅



ITMH03--**I₄₂



ITM

ITMH

ITMS

STFC

STFD

CRM-HA


CRM-HB

CRM-PS


SMA6V

SMA2F

ITMH06 外形及安装尺寸/ ITMH06 Installation Dimensions




标准外花键 : ITMH06---
Standard Involute Spline : ITMH06---




ITMH06---SL₃

标准平键 : ITMH06---B
Standard Parallel Key : ITMH06---B






ITMH06---SL₂


标准内花键 : ITMH06---I
Standard Female Spline : ITMH06---I




ITMH06---N




ITMH06--**N₁




ITMH06--**B₂





ITMH06--**B₄





ITMH06--**B₁₃




ITMH06--**I₁₁




ITMH08 外形及安装尺寸/ ITMH08 Installation Dimensions




标准外花键 : ITMH08--**
Standard Involute Spline : ITMH08--**




标准平键 : ITMH08--**B
Standard Parallel Key : ITMH08--**B




ITMH08--**6M





ITMH08--**6MB



ITMH08--**H54



ITMH11 外形及安装尺寸/ ITMH11 Installation Dimensions









标准外花键 : ITMH11-***
Standard Involute Spline : ITMH11-***

标准外花键 : ITMH11-H54
Standard Involute Spline : ITMH11-H54

标准平键 : ITMH11-***B
Standard Parallel Key : ITMH11-***B

标准内花键 : ITMH11-***I
Standard Female Spline : ITMH11-***I



ITM

ITMH

ITMS

STFC

STFD

CRM-HA


CRM-HB

CRM-PS


SMA6V

SMA2F


ITMH11--**SL₃




ITMH11--**SL₄




ITMH11--**SM₄




ITMH11--**B₆




ITMH11--**N₁




ITMH11--**N₂




ITMH11--**I₂₁




ITMH11--**I₂₂




ITMH11--**SL₅




ITMH11--**B₄



ITMH16 外形及安装尺寸/ ITMH16 Installation Dimensions




标准外花键 : ITMH16-**
Standard Involute Spline : ITMH16-**




标准平键 : ITMH16-**B
Standard Parallel Key : ITMH16-**B


标准内花键 : ITMH16-***I
Standard Female Spline : ITMH16-***I






ITMH16-**SL₅




ITMH16-**SM₄




ITMH16-***N




ITMH16---**B₆




ITMH16---**B₁₇




ITMH16---**B₁₉




ITMH16---**D




ITMH16---**B₃₀




ITMH16---**I₃₂



ITMH16---**I₄₂



ITMH16---**I₈₂



ITMH16---**11M

